Installation and mounting manuals for **EK-Mosfet ASUS M4A** water block:

This product is intended for expert users. Please consult with a qualified technician for installation. Improper installation may result in damage to your components. EK Water Blocks assumes no liability whatsoever, expressed or implied, for the use of these products, nor their installation. The following instructions are subject to change without notice. Please visit our web site at www.ekwaterblocks.com for updates.

Remove original heat sink from the motherboard. Remove plastic foil cover from both sides of the thermal pad. Cover mosfet chips with thermal pad. Put on the water block.



Picture 1: ASUS M4A Motherboard

Picture 2: ASUS M4A Water block

Place backplate with rubber pad under motherboard and use enclosed $M3 \times 10$ mm screws with plastic washer to install the Mosfet cooler (as shown on picture 2). Do not use high force to tighten the block, because the motherboard can bend or get damaged.

VERY IMPORTANT NOTICE:

Once the installation is completed, it is a recommended practice to test the cooling circuit for leaks prior to powering up the computer. We recommend a 24 hour leak test prior to powering up the computer. Do not test the water block using city water pressure. This will rupture the top of the housing and render the block unusable (and will void your warranty).

WARRANTY:

Our products are warranted against defects in materials or workmanship for a period of 24 months beginning from the date of delivery to the final user. During this period, products will be repaired or have parts replaced at our discretion provided that: (I) the product is returned to the agent from whom it was purchased; (II) the product has been purchased by an end user and has not used for commercial purposes; (III) the product has not been misused, handled carelessly, or used in a manner other than in accordance with the instructions provided describing its installation and proper use. This warranty does not confer rights other than those expressly set out above and does not cover any claims for consequential loss or damage. This warranty is offered as an extra benefit and does not affect your statutory rights as a consumer. This warranty is voided if the product comes in contact with aggressive UV additives.

Installation and mounting manuals for **EK-Mosfet ASUS M4A** water block:

This product is intended for expert users. Please consult with a qualified technician for installation. Improper installation may result in damage to your components. EK Water Blocks assumes no liability whatsoever, expressed or implied, for the use of these products, nor their installation. The following instructions are subject to change without notice. Please visit our web site at www.ekwaterblocks.com for updates.

Remove original heat sink from the motherboard. Remove plastic foil cover from both sides of the thermal pad. Cover mosfet chips with thermal pad. Put on the water block.



Picture 1: ASUS M4A Motherboard

Picture 2: ASUS M4A Water block

Place backplate with rubber pad under motherboard and use enclosed $M3 \times 10$ mm screws with plastic washer to install the Mosfet cooler (as shown on picture 2). Do not use high force to tighten the block, because the motherboard can bend or get damaged.

VERY IMPORTANT NOTICE:

Once the installation is completed, it is a recommended practice to test the cooling circuit for leaks prior to powering up the computer. We recommend a 24 hour leak test prior to powering up the computer. Do not test the water block using city water pressure. This will rupture the top of the housing and render the block unusable (and will void your warranty).

WARRANTY:

Our products are warranted against defects in materials or workmanship for a period of 24 months beginning from the date of delivery to the final user. During this period, products will be repaired or have parts replaced at our discretion provided that: (I) the product is returned to the agent from whom it was purchased; (II) the product has been purchased by an end user and has not used for commercial purposes; (III) the product has not been misused, handled carelessly, or used in a manner other than in accordance with the instructions provided describing its installation and proper use. This warranty does not confer rights other than those expressly set out above and does not cover any claims for consequential loss or damage. This warranty is offered as an extra benefit and does not affect your statutory rights as a consumer. This warranty is voided if the product comes in contact with aggressive UV additives.