
EK-Quantum Velocity² - AM5 Backplate







Please note the installation of the product is intended to be undertaken by an adequately trained and experienced person. You are installing the product at your own risk. If you are not properly trained or experienced or feel unsure about the installation procedure, please refrain from installing the product yourself and contact our tech support for assistance. We disclaim our liability for any damages to the product as well as incidental, consequential, or indirect damages incurred due to improper or inappropriate installation.

Before you start using this product, please follow these basic guidelines:

Please carefully read the manual before beginning the installation process.

The EK Fittings require only a small amount of force to screw them firmly in place since the liquid seal is ensured by the rubber O-ring gaskets.

The use of corrosion inhibiting coolants is always recommended for liquid cooling systems, and mandatory for nickel-plated water blocks.


Do not use pure distilled water! For best results, EK recommends the use of EK-Cryo Fuel coolants.

Make sure to thoroughly bleed air out of your water block, or you will not reach optimal performance.


TABLE OF CONTENTS

DX CONTENTS	4
ACKPLATE DIMENSIONS	5
REPARING THE AM4 WATER BLOCK FOR UPGRADE	6
REPARING THE AM5 MOTHERBOARD	7
ISTALLING THE WATER BLOCK	9
DNNECTING THE D-RGB LED STRIP	1
ESTING THE LOOP	1
ARRANTY	12
JPPORT AND SERVICE	13
DCIAL MEDIA	13






BACKPLATE DIMENSIONS



PREPARING THE AM4 WATER BLOCK FOR UPGRADE






Important! Before starting, make sure to have a clean, flat surface to work on. It is recommended to put foam or soft material to lay a motherboard on.

STEP 1


If the EK-Quantum Velocity2 AM4 water block is already installed, remove the backplate from the motherboard's backside using Allen Key 2.5 mm (As shown in the picture).




STEP 2

Detach the water block from the motherboard and save it for later steps. Clean the CPU cold plate using a non-abrasive cloth or Q-tip.

PREPARING THE AM5 MOTHERBOARD






STEP 1


Using a Philips-head screwdriver remove the four screws securing the original plastic hold-down clamps around the socket as shown in the illustration. Remove the hold-down clamps and store them away.

STEP 2

After removing the plastic hold-downs, additional four (4) Screws must be removed using provided TX20 L-shaped wrench. After removing the screws, detach the factory-provided backplate. Save the backplate screws for the next step.

For this step, you will need:







STEP 3

Attach the AM5 Backplate and secure it with the four (4) saved backplate screws.

Do not peel off the protective sticker from the AM5 Backplate!


For this step, you will need:





STEP 4

Cleaning the CPU: Wipe the IHS clean using a non-abrasive cloth or Q-tip as shown in the illustration.



STEP 5

Applying thermal compound: Apply the enclosed thermal grease (thermal compound) on the CPU heat spreader – IHS – as shown in the image. The layer of the thermal compound must be thin and even in thickness over the entire surface of the IHS.




The excessive or uneven application of thermal grease may lead to poor performance!

For this step, you will need:




INSTALLING THE WATER BLOCK




STEP 1

Position the AM4 CPU Water Block onto the AM5 Motherboard. Make sure to align the holes (as shown in the picture).

Make sure to double-check the layer of the Thermal Grease before placing the water block onto the motherboard.





STEP 2

Secure the water block from the backside of the motherboard using the included Allen Key 2.5mm.

Start fastening the screws in a cross pattern. Do not tighten fully until all of the screws are partially screwed in.

The Allen Key 2.5mm must be used in a standing position! Otherwise, the mounting screws may crack during tightening!

Make sure to orientate the backplate as illustrated. Incorrect installation of the backplate may result in damage to the motherboard.

For this step, you will need:

Allen Key 2.5 mm	


STEP 3

With EK-Velocity $^{\rm 2}$ series water blocks, it is mandatory to use the bottom port as the INLET.

Mixing the ports may result in poor thermal performance of the water block.

Tighten the fittings in a clockwise direction until the gasket underneath is compressed. The installation of the Velocity² water block is now complete.

CONNECTING THE D-RGB LED STRIP



STEP 1

Plug the 3-pin connector from the water block's D-RGB LED light to the DRGB HEADER on the motherboard. The LED will work if the pin layout on the header is as follows: **+5V**, **Digital**, **empty**, **Ground**.



Please ensure that the arrow indicated on the connector is plugged into the +5V line as indicated on your motherboard. If you put the LED Diode to the 12V RGB HEADER you can damage the LEDs. Failure to do so will damage your motherboard or LED strip.

TESTING THE LOOP

To make sure the installation of EK components was successful, we recommend you perform a leak test for 24 hours. When your loop is complete and filled with coolant, connect the pump to a PSU outside of your system. Do not connect power to any of the other components. Turn on the PSU and let the pump run continuously. It is normal for the coolant level to drop during this process as air collects in the distribution plate. Inspect all parts of the loop, and in the eventuality that coolant leaks, fix the issue and repeat the testing process. Ensure that all hardware is dry before the system is powered on in order to prevent any damage.



Our products are warranted against defects of materials and guality for a period of 24 months, starting with the date of delivery to the end-user. During this period, products will be repaired or have parts. replaced at our discretion, provided that 1) the product is returned to the agent from whom it was purchased; 2) the product has been purchased by the end-user and has not been used for commercial purposes; 3) the product has not been misused, handled carelessly, or used in a manner other than the way described in the instructions manual. This warranty does not confer rights other than those expressly set out above and does not cover any claims for consequential loss or damage. This warranty is offered as an extra benefit and does not affect your statutory rights as a consumer. This warranty is voided if the product comes in contact with aggressive UV additives or other improper liquids. EK water blocks are sealed with a warranty-voiding circular label, proving the water block has withstood a pressure leak test. Removing the label will void the leak-free guarantee, but not the guarantee on the product itself. Any other RMA issues can be reported to EK Customer Support at www.ekwb.com/support for further analysis.

SUPPORT AND SERVICE

In case you need assistance or wish to order spare parts or a new mounting mechanism, please contact: https://www.ekwb.com/customer-support/


EKWB d.o.o. Pod lipami 18 1218 Komenda Slovenia - FU

SOCIAL MEDIA

F EKWaterBlocks



☑ @EKWaterBlocks



EKWBofficial

