

This product is intended for installation only by expert users. Please consult with a qualified technician for installation. Improper installation may result in damage to your equipment. EK Water Blocks assumes no liability whatsoever, expressed or implied, for the use of these products, nor their installation. The following instructions are subject to change without notice. Please visit our web site at [www.ekwb.com](http://www.ekwb.com) for updates. Before installation of this product please read important notice, disclosure and warranty conditions printed on the back of the box.

Before you start using this product please follow these basic guidelines:


1. **Please carefully read the manual before through before beginning the installation process!**
2. **Please remove your motherboard from the computer to assure safest mounting process in order to prevent any possible damages to your CPU and/or motherboard's circuit board (PCB).**
3. **The EK High Flow and EK-CSQ type fittings require only a small amount of force to screw them firmly in place since the liquid seal is ensured by the rubber O-ring gaskets.**
4. **The use of quality, market proved corrosion inhibiting coolants is always strongly recommended for any liquid cooling system.**

## STEP 1: GENERAL INFORMATION Sample photo of Gigabyte GA-X99 motherboard



## STEP 2: PREPARING YOUR MOTHERBOARD

1. **REMOVING STOCK COOLER.** Remove all encircled screws on the back of the motherboard in order to remove the factory installed MOSFET/NB- as well as SB cooling solution.




2. **CLEANING THE PCB.** Carefully detach the original stock cooler after removing **all** screws securing it to the board. Wipe off the remains (by using non-abrasive cloth or *qtip*, as shown on sample photo) of the original thermal compound until the components and circuit board are completely clean. EKWB recommends the use of denatured alcohol for removing TIM leftovers.




3. **APPLYING THERMAL COMPOUND.** Apply thermal compound: lightly coat the *Intel X99 PCH (SB)* with electrically non-conductive thermal grease - for example Arctic Cooling MX-2™, MX-4™ or GELID GC-Extreme™. EKWB recommends to apply the thermal grease in cross form for the best performance (see sample picture).



4. **CUTTING THERMAL PADS.** Your block comes with thermal pads, some of which are already pre-cut. Others have to be cut to smaller pieces in order to cover all the VRM components such as MOSFETs and drivers. **PLEASE REMOVE THE PROTECTIVE FOIL FROM BOTH SIDES OF THE THERMAL PADS PRIOR TO INSTALLATION.**  
Replacement thermal pad: Thermal PAD A 1,0 mm - (100 x 16 mm), Thermal PAD A 0,5 mm - (100 x 16 mm)




5. **PLACING THERMAL PADS ON MOTHERBOARD.** Place the thermal pads you cut on a PCB as shown in the picture below (PLEASE REMOVE THE PROTECTIVE FOIL FROM BOTH SIDES OF THE THERMAL PADS PRIOR TO INSTALLATION). EK recommends using small drops of electrically non-conductive (for example: Arctic Cooling MX-2™, MX-4™ or GELID GC-Extreme™) thermal grease on each phase regulator (that is being covered with thermal pad; see picture below) in order to even further improve the thermal performance of the EK-FB GA-X99 series water block.



### STEP 3: PREPARING YOUR WATER BLOCK


PLACING SB AND MOSFET BLOCK ON MOTHERBOARD. Place the EK-FB KIT GA-X99 water block with pre-installed standoffs gently to the motherboard or vice versa. Make sure that mounting holes are aligned. **Between waterblock and PCB use plastic washer and glue it on to the standoffs if not pre-glued!!!**



### STEP 4: ATTACHING THE BLOCK TO THE MOTHERBOARD


Prior to fastening the screws please make sure the mounting holes on the motherboard's circuit board are aligned with water block.

Use 5 (five) (4 (four) for GA X99 SOC FORCE) M2.5x4 and 2 (two) M3x4 DIN7985 screws and 6 (six) (7 (seven) for GA X99 SOC FORCE) PVC washers. Tighten the screws, beginning near the center of the board and continue evenly outwards. EK recommends installing loosely first all the screws and only then start fastening them. Do not use excessive force when tightening the screws! Use the enclosed screws and washers as shown in picture below:



### STEP 5: CHECKING FOR CONTACTS


Temporarily remove the waterblock to check for uniform surface contact between the block and the components. Note the pattern of contact on a piece of paper. Then repeat steps 3 and 4 to reattach the block applying more or less pressure to the areas where you have found it necessary. Note that there is no need for perfect thermal pad imprint on the inductors/coils (mentioned in STEP2)



### 6. POSITIONING FITTINGS AND CONNECTING TO WATER CIRCUIT

Attach the liquid cooling tubes and connect the water-block(s) into the cooling circuit. EKWB recommends using EK-CSQ compression fittings with the EK-FB GA X99 series water block. You can use any opening as an inlet/outlet port. Plan your tubing routing in advance!

**The maximum diameter of compatible fitting is 22.2mm. All EK-CSQ series fittings can be used with this water block. However when using fitting bigger than EK-CSQ Fitting 10/13mm it is mandatory to use EK-CSQ Extender 8mm.**



### REQUIRED TOOLS AND MOUNTING SCREWS:

